

XP1  
RJ11 (6P6C)

Цепь	Кон
Тх0	1
Рх0	2
HOLD	3
+5В	4
Общии	5

XP2  
RJ11 (6P6C)


Цепь	Кон
Тх0	1
Рх0	2
HOLD	3
+5В	4
Общии	5

XP3

Цепь	Кон
GND	1
GND	2
+35V	3
+35V	4
---	5
---	6
PUSK2	7
POMP2	8
INP2	9
KLAP2	10
PUSK1	11
KLAP1	12
INP1	13
POMP1	14
---	15
---	16
+U	17
+U	18
-U	19
-U	20

XP4

Цепь	Кон
~220V	1
~220V	2



DD5-007 (10)  
DD1 (40), DD2 (8)  
DD3 (16), DD4 (14)  
DD1 (20), DD2 (4)  
DD3 (8), DD4 (7)  
DD5-007 (9)

DA1-DS1833; DA2, DA3-KP142EHSB  
DD1-P87C51FA; DD2-M24C01A; DD3-74HC174N  
DD4-K561T/1; DD5-007-K1109KH2.